

ABS™ Tester

- Tone TRACE feature detects tracing tone signal to locate cables
- Receives and reproduces telephone system dial tone
- Indicates call addressing for correct telephone number
- Polarity indicator tests for correct wiring and power
- Volume control adjusts test and dial tones
- Used for analog voice system testing and maintenance
- RJ-11 modular cord and alligator clip lead sets included
Includes 9 volt battery



Description	Cat. No.
ABS™ Tester	62-180

ABS™ Signal Thrower™

- Works with the ABS™ Tester to locate and identify cables
- Emits three different types of signals
- Auto-off after 3 hours of non-use
- RJ-11 modular cord and alligator clip lead sets included
Includes 6 volt battery



Description	Cat. No.
ABS™ Signal Thrower™	62-184

ABS™ Tester/ABS™ Signal Thrower™ Kits



Kit 33-852 Includes:

Description	Qty.	Cat. No.
ABS™ Signal Thrower™	1	62-184
ABS™ Tester	1	62-180
Lead Set	1	K-8690
Cable Assembly	1	K-7919
Hard Gray Case	1	—



Kit 33-854 Includes:

Description	Qty.	Cat. No.
ABS™ Signal Thrower™	1	62-184
ABS™ Tester	1	62-180
Lead Set	1	K-8690
Cable Assembly	1	K-7919
Soft Pouch	1	62-105

Kit 62-188 Includes:

Description	Qty.	Cat. No.
ABS™ Signal Thrower™	1	62-184
ABS™ Tester	1	62-180
Lead Set	1	K-8690
Cable Assembly (blister card)	1	K-7919