

Canada





Collaborators

- Pablo A. Turner IFIR, Argentina
- Carlos Tomé LANL, USA
- Rick Holt Queens University, Canada
- Richard Sauvé AECL, Canada
- John Root NRC, Canada
- Ron Roggé NRC, Canada




OUTLINE

- Background
- Neutron Diffraction Set-up and Results
- Modeling
- Comparison of Neutron Diffraction and Numerical Results
- Summary



Candu Power Generation System





Fuel Channel





FIGURE 2.2-3 REACTOR CORE SCHEMATIC




Fretting/Debris Flaws






Zirconium Hydride Precipitation






"Cookie-cutter" method of creating a compact toughness specimen from a pressure tube.






Neutron Scanning Path






Neutron Scattering Apparatus for Constant Strain CTS T = 250°C, 300°C



- a) spring-loaded mount
- b) extensometer
- c) glass-rod extension
- d) thermocouples
- e) neutron beam-defining slit (0.5 mm x 2 mm)
- f) load cell



Macroscopic Stress Relaxation Zr-2.5Nb CT Specimen




Average readout of load cell over each scan of positions.

Temperature stability on specimen +/- 2°C.



Distribution of Strain on the CTS Notch Plane T=300°C





Material Constitutive Law

The highly anisotropic plastic and creep properties of the Zr-2.5Nb HCP material are simulated using a non-linear self-consistent polycrystalline code, SELFPOLY.

$$\dot{\boldsymbol{\varepsilon}} = f(\boldsymbol{\varepsilon}_c^{ef}, T, \boldsymbol{\sigma}^{ef}) \dot{\boldsymbol{\varepsilon}}^{IT}(\boldsymbol{\sigma})$$

 $\dot{\varepsilon}$ is the strain rate tensor,


 $f(\varepsilon_c^{ef}, T, \sigma^{ef})$ is a scalar function that accounts for work hardening and temperature changes

 $\dot{\epsilon}^{\pi}(\sigma)$ is the tensor from the interpolation table that gives the anisotropy of the material at a stress tensor σ .


The interpolation table is determined using SELFPOLY, which represents the weighted average of the creep response exhibited by individual crystal grains. This has been incorporated as a material subroutine into the finite element code, H3DMAP




Analytical(2-D) / Experimental Comparison of the Elastic Strain Normal to the Notch Plane




Stress Contours Normal to the Notch Plane at 0.0h








3-D Curved CTS Model






3-D Strain Variation on the Notch Plane Neutron Sample Volume





3-D Analytical / Neutron Diffraction Notch Plane Results





Summary

- Both the analytical and experiment techniques have shown that the stress relaxation that occurs ahead of the notch is primarily due to thermal creep
- A good agreement is found when the 3-D analytical results are determined within the volume of the neutron diffraction scanning technique.
- Constant load tests are currently being evaluated
- Neutron scanning rate is not fast enough