

Self-assembled Nanoclusters in Oxide-dispersion-strengthened Steel

Xun-Li Wang

Spallation Neutron Source

Oak Ridge National Laboratory



Supported by DOE, Basic Energy Sciences

PI: C. T. Liu, ORNL

ODS Steel Containing Y-Ti-O Nanoclusters Exhibits Outstanding Mechanical Properties at High Temperature

- Creep rate is reduced by six orders of magnitude in ODS steel containing Y-Ti-O


Atom probe showed that Y-Ti-O form nanoscale clusters that are highly stable even at high temperatures





Key Questions for neutron scattering studies

- **Structure of the nanocluster**
- **Thermal stability**

Y-Ti-O Containing Steel Is Highly Stable Even at 1250 C



Samples Prepared by A Different Method Shows a Transition at 1250 C




Diffraction peaks disappear at 1250 C

In-situ Small Angle Scattering Work Are Underway

- **To study the thermal stability of the nano clusters**
 - **Challenges: Furnaces that can go above 1300 C**
- **It would be nice to do both diffraction and small angle scattering at the same time**
 - **Several SNS instruments are designed with this need in mind**

My Dream Experiment


- **Measurements of scattering data over multiple or continuous Q-range**
 - To study the multi length scale phenomena (e.g., phase transformation)
 - Time-resolved
- **Simultaneous characterization capabilities**
 - DSC
 - Dilatometry
 - Transport properties
- **A variety of sample environments**
 - Temperature
 - Applied load
 - Electric or magnetic fields



The VULCAN diffractometer is designed with these needs in mind

In-situ Neutron Diffraction Studies to 1300 C Demonstrated the Thermal Stability of Mechanically-Alloyed ODS Steel

Room temperature diffraction patterns after heating to 1300 C



Mechanically alloyed ODS steel are stable after heating to 1300 C

The other ODS steel recrystallized and grew into single crystals

